



ASCOM OFFICE® M  
 INCREASING THE MOBILITY OF YOUR  
 STAFF IMPROVES THE PRODUCTIVITY  
 OF YOUR BUSINESS.



**Direct access gives direct benefits**

Office M is an elegant portable handset for retail, education and enterprise business environments that keeps your staff connected. Powerful messaging – text messages are visible even in the middle of a call – helps to keep your personnel up-to-date at all times. Furthermore, high quality voice facilitates immediate response and a more efficient use of time, even on the move. And with 11 pre-installed languages, not only is Office M a truly international solution, it also eliminates time wasting due to language confusion.

**Packed with smart features**

The Office M is packed with features that are designed to save time and money. The intuitive interface which includes time and date on-screen, means less training is required for the user.

Direct access to a centrally updated phone book, complemented by large Personal and Company phone books, prevents the frustration of dealing with out-of-date numbers. One key access to voice mail saves even more time. Hands-free and loudspeaker functions allow you to talk and work at the same time. Useful extras such as an alarm clock and calculator are there when you need them.

**Making a real-life difference**

Mobility is emerging as a core asset for successful businesses. Office M paves the way to greater flexibility and efficiency with features and accessories that address the needs of a variety of businesses at an attractive price. For more information on how an Ascom solution can benefit your enterprise, contact us at 877-71ASCOM or visit [ascomwireless.com](http://ascomwireless.com).

OfficeM features at a glance		
<b>Powerful messaging capabilities</b> View messages during a call, receive instant messages and send text messages.	<b>Hands-free function</b> Built-in hands-free and loudspeaker allows you to talk and work simultaneously.	<b>Personalization</b> Key sound, discrete ringing, melody selection, vibrating alert, key lock, PIN code, language, display contrast, etc.
<b>Redial</b> Redial the last 20 dialed, answered and missed calls.	<b>Missed call function</b> Check Who Called? message indicates missed call.	<b>Easy access to voicemail</b> An icon indicates new voice-mail, accessed by pressing a pre-programmed key.
<b>Handset and key lock</b> Prevents unauthorized use with PIN code and key lock.	<b>Large graphic display</b> Six lines of text and icons are shown on the illuminated adjustable contrast display.	<b>Vibration alert</b> For noisy environments or when discretion is required.
<b>Phone books</b> Personal (100 entries). Add, delete or modify entries directly, or use Cordless Phone Manager (CPM). Supports Call-by-Name and Quick Call-by-Name. Company (1000 entries). For numbers common to all users. Downloaded using the CPM software tool. Company and Personal phone books can be searched simultaneously. Access to Central Phone Book. Directly access a common database with unlimited entries, providing instant up-to-date information.	<b>Advanced system features</b> System dependent. May require additional equipment. <ul style="list-style-type: none"> <li>• Message Waiting Indication</li> <li>• Message key</li> <li>• Calling Line Identification Presentation</li> <li>• Connected Line Presentation</li> <li>• Calling Name and number recognition</li> <li>• Time and date</li> </ul>	<b>Accessories</b> <ul style="list-style-type: none"> <li>• Headsets with microphone on cable or boom</li> <li>• Desktop charger</li> <li>• Charging rack</li> <li>• Swivel clip</li> <li>• Leather case</li> <li>• Cordless Phone Manager</li> </ul>

OfficeM technical specifications		
<b>Size</b> 5.63" x 2.09" x 1.02" <b>Weight</b> 4.2 oz. <b>Color</b> MagicGrey, Silver <b>Display</b> 101 x 80 px LCD. White back light <b>Clip</b> Hinge type (standard) or swivel <b>Subscriptions</b> 8 systems, auto or manual selection	<b>Phone book</b> Maximum name length: 12 characters Maximum number length: 24 digits Entries: 1100 (max. 1000 in the Company phone book; max. 100 in the Personal book) plus access to central phone book with unlimited entries.	<b>Messaging (SMS)</b> Maximum message length: 160 characters. Some characters require 2 bytes in the final message, therefore the user will sometimes not be able to enter 160 characters.
<b>Battery</b> Type: 850 mAh (Li-Ion) Talk / Standby time: 20h / 140h Charging time: 4h	<b>Environmental</b> Operating temperature: 32 to 104° F Storage temperature: -68 to 131° F	<b>Languages</b> Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Portuguese, Spanish, Swedish, plus one additional programmable language.
<b>Connectors</b> Headset/accessory: Contact dealer for information on the headset and programming tools. Battery: Used when charging battery.	<b>Telephony</b> Indication: ring signal (14 pre-programmed, 10 downloaded melodies configured by the CPM), flashing LED and vibration. Answer call: push button or auto answer. Call list capacity: 20 calls with time stamp (max. 10 dialed calls, max. 10 received or missed calls). If a number occurs more than once, the last time stamp is shown together with the total number of occurrences.	<b>Volume</b> Earpiece: Adjustable in 10 steps Ringer signal: Adjustable in 9 steps
<b>Radio</b> SAR10g (Specific Absorption Rate): 0,06 mW/g	<b>Endurance</b> Enclosure protection: IP 40, IEC 60529 Free fall test: IEC 68-2-32, dropped 12 times from 1 m	<b>EMC Standard</b> FCC Part 15

Specifications are subject to change without notice.